

Marka	Aparat	Obudowa/peleryna	Wymagane dodatkowe akcesoria
Canon	PowerShot G11	D-AX	C-A58
Canon	PowerShot G10	D-AX	C-A58
Canon	PowerShot S5 IS	D-AX	C-A58
Canon	Powershot SX 110 IS	D-AX	
Canon	Powershot SX101	D-AX	
Nikon	Coolpix P5000	D-AX	
Nikon	Coolpix P5100	D-AX	
Nikon	Coolpix P6000	D-AX	
Sony	DSC-H1	D-AX	C-A58
Sony	DSC-H2	D-AX	C-A58
Sony	DSC-H5	D-AX	C-A58
Sony	DSC-S70	D-AX	
Sony	DSC-S75	D-AX	
Sony	DSC-S85	D-AX	
Sony	MVC-CD 1000	D-AX	
Sony	MVC-CD 200	D-AX	
Sony	MVC-CD 300	D-AX	
Sony	MVC-CD 400	D-AX	
Sony	MVC-CD 500	D-AX	
Panasonic	DMC-GF1C	D-AX	
Panasonic	DMC-GF1K	D-AX	