

Marka	Aparat	Obudowa/peleryna	Wymagane dodatkowe akcesoria
Canon	EOS 40D	U-AXP	
Canon	EOS 450D	U-AXP	
Canon	EOS 50D	U-AXP	
Canon	EOS 500D	U-AXP	
Nikon	D40	U-AXP	
Nikon	D40x	U-AXP	
Nikon	D50	U-AXP	
Nikon	D60	U-AXP	
Nikon	D70	U-AXP	
Nikon	D70s	U-AXP	
Nikon	D80	U-AXP	
Nikon	D90	U-AXP	
Olympus	E-410	U-AXP	
Olympus	E-420	U-AXP	
Olympus	E-510	U-AXP	
Olympus	E-520	U-AXP	
Sony	DSC-D770	U-AXP	C-A62
Sony	DSLR-A100	U-AXP	
Sony	DSLR-A200	U-AXP	
Sony	DSLR-A300	U-AXP	
Sony	DSLR-A350	U-AXP	
Panasonic	DMC-GH1	U-AXP	