

| Marka | Aparat | Obudowa/peleryna |
|--------------|---------------|-------------------------|
| Canon | EOS 40D | U-B |
| Canon | EOS 50D | U-B |
| Canon | EOS 5D | U-B |
| Nikon | D200 | U-B |
| Nikon | D3S | U-B |
| Nikon | D3 | U-B |
| Nikon | D300 | U-B |
| Nikon | D700 | U-B |
| Olympus | E-3 | U-B |
| Sony | DSLR-A700 | U-B |
| Sony | DSLR-A900 | U-B |
| Sony | DSLR-A500 | U-B |
| Sony | DSLR-A230 | U-B |